

## DMX Channel Modes, Assignments, and Values

8-Channel	Channel	Function	Value	Setting
1	Fog		000 ⇔ 009	No function
			010 ⇔ 255	Fog on
2	Red		000 ⇔ 009	No function
			010 ⇔ 255	0~100%
3	Green		000 ⇔ 009	No function
			010 ⇔ 255	0~100%
4	Blue		000 ⇔ 009	No function
			010 ⇔ 255	0~100%
5	Color Mixing		000 ⇔ 009	No function
			010 ⇔ 255	Color mixing
6	Auto Speed		000 ⇔ 009	No function
			010 ⇔ 255	Speed, slow to fast
7	Strobe		000 ⇔ 009	No function
			010 ⇔ 255	Strobe, slow to fast
8	Dimmer		000 ⇔ 009	No function
			010 ⇔ 255	0~100%